



Powderhorn INDUSTRIES, Inc.



Washing and Drying vinyl-backed Adult Bibs


These bibs are of vinyl-backed terrycloth. Yours may be Navy Blue or Forest Green (The Stain Hider™ colors), or White.

You can help your facility get good value from these bibs by carefully following these laundering instructions.

Making these bibs last longer will actually **save you work**. Because these bibs don't let fluids through onto residents' clothes, **you'll wash less personal clothing**.

So...save yourself some work by following these laundering instructions!

Washing Instructions Developed In Cooperation With Ecolab, Inc.

<u>Operation</u>	<u>Water Level</u>	<u>Temp.</u>	<u>Time (min.)</u>	<u>Supplies for 100 lb. Rated Equipment</u>	<u>Notes</u>
1. Suds/Bleach	Low	140-160	6-8	8-14 oz. Tri-Star L-2000 2-4 oz. Oyx-Brite or other oxygen bleach	 Chlorine Bleach
2. Rinse	High	100-120	3	—	—
3. Extract	—	—	2	—	Optional extract to improve rinsing
4. Rinse	High	100-120	3	—	—
5. Rinse	High	100-120	3	—	—
6. Final Rinse	Low	100-120	4	2-3 oz. Aqua Soft or Solid Soft	Optional to reduce static
7. Extract	—	—	4-6	—	—
8. Dry	—150° maximum until just dry, then use cool-down cycle				

Recommendations may vary, depending upon soil levels, water hardness, and your equipment. Your local Ecolab specialist can design a wash formula specifically for your conditions.

Alternate detergents: Tri-Star Glo, Tri-Star Vector, Tri-Star Re-4000, Eco-Line Vector 2, Solid Brite, Solid Star, Solid Surge.



- DON'T USE CHLORINE BLEACH. NONE! NEVER!**
Use oxygenated "All fabric" bleach, but only when necessary. Use as little as possible, too.
- DRY BIBS AT 150° Or Lower**
They'll still dry quickly, and you'll be helping make them last even longer.
Don't overdry, and use the cool-down cycle after the drying cycle.

BLEACHING AND HIGH HEAT DRYING will harden and crack the vinyl waterproof layer of the bibs. And it will void Powderhorn's guarantee! Please don't!

Questions? Problems? Suggestions? Call 1-800-336-1414

Powderhorn Industries, 931 North Park Ave., Box 1443, Montrose, CO 81402